





ANTI-LOCK BRAKE SYSTEM CIRCUIT

SYSTEM CIRCUIT INSPECTION

1. INSPECT SYSTEM CIRCUIT WITH CONNECTOR CONNECTED


- Remove the ABS ECU.
- Using a voltmeter with high impedance (10 k Ω /V minimum), measure the voltage at each terminal and body ground.



R07807

Tester Connection	Check item	Condition	Specified Value	Trouble Part
SFRH	Voltage	IG switch 4N and "ABS" warning light goes o	10 - 14 V	Actuator
SFRR	Voltage	IG switch ON and "ABS" warning light goes o	10 - 14 V	
SR	Voltage	IG switch ON and "A6S" warning light goes on	About 0 V	ABS ECU
FR-	Continuity	IG switch OFF	Continuity	
RL-	Continuity	IG switch OFF	Continuity	
TS	Voltage	IG switch ON and data link connector 1 Ts -E1 not connected	10 - 14 V	
		IG switch ON and data link connector 1 Ts -E1 connected	About 0 V	
GS2	Voltage	IG switch ON	4 - 6 V	Deceleration Sensor
EXI	Voltage	IG switch ON and 4WD indicator light goes off	10 - 14 V	GAUGE Fuse
PKB	Voltage	IG switch ON and PKB lever pulled	About 0 V	Parking brake switch
		IG switch ON and PKB lever returned	10 - 14 V	Level warning switch
IG1	Voltage	1G switch ON	10 - 14 V	ECU-IG Fuse
SFLR	Voltage	IG switch ON and "ABS" warning light goes off	10 - 14 V	Actuator
SFLH	Voltage	IG switch ON and "ABS" warning light goes off	10 - 14 V	
AST	Voltage	IG switch ON and "A6S" warning light goes off	About 0 V	ABS ECU
		IG switch ON and 'ASS' warning light goes on	10 - 14 V	
WA	Voltage	IG switch ON and "ABS" warning light goes on	About 0 V	
		IG switch ON and "ABS" warning light goes off	10 - 14 V	
FL-	Continuity	IG switch OFF	Continuity	
R-	Continuity	IG switch OFF	Continuity	ABS ECU
FSS	Continuity	IG switch OFF	Continuity	
RR-	Continuity	IG switch OFF	Continuity	
GS1	Voltage	IG switch ON	4 - 6 V or 7 - 12 V	Deceleration Sensor
TC	Voltage	IG switch ON and data link connector 1 Tc-E1 not connected	10 - 14 V	ABS ECU
		IG switch ON and data link connector 1 Tc- E1 connected	About 0 V	
STP	Voltage	IG switch OFF and brake pedal depressed	8 - 14 V	Stop light switch
	Continuity	IG switch OFF and brake pedal returned	Continuity	Stop light
BAT	Voltage	IG switch OFF	10 - 14 V	DOME Fuse
RSS	Continuity	IG switch OFF	Continuity	ABS ECU
SRR	Voltage	IG switch ON and "ABS" warning light goes off	10 - 14 V	Actuator
SRH	Voltage	IG switch ON and "ABS" warning light goes off	10 - 14 V	

If the circuit is not as specified, check and repair or replace the trouble part shown in the table above.



2. INSPECT SYSTEM CIRCUIT WITH CONNECTOR DISCONNECTED

- (a) Disconnect the connectors from the ECU, inspect at the wire harness side connector.

Tester Connection	Check Item	Specified Value	Trouble Part	Tester Connection	Check Item	Specified Value	Trouble Part
SFRH ↔ Body Ground	Resistance	About 5.0 Ω	Actuator	SFLR ↔ Body Ground	Resistance	About 2.2 Ω	Actuator
SFRR ↔ Body Ground	Resistance	About 2.2 Ω	Actuator	SFLH ↔ Body Ground	Resistance	About 5.0 Ω	Actuator
MR ↔ R-	Resistance	56 – 68 Ω	Control relay	AST ↔ Body Ground	Resistance	About 5.0 Ω	Actuator
SR ↔ R-	Resistance	72 – 88 Ω	Control relay	FL+ ↔ FL-	Resistance	0.89 – 1.29 kΩ	LN Front speed sensor
FR+ ↔ FR-	Resistance	0.89 – 1.29 kΩ	RH Front speed sensor	RR+ ↔ RR-	Resistance	1.05 – 1.45 kΩ	RH Rear speed sensor
MT ↔ Body Ground	Continuity	Continuity	Actuator	SRR ↔ Body Ground	Resistance	About 2.2 Ω	Actuator
RL+ ↔ RL-	Resistance	1.05 – 1.45 kΩ	LH Rear speed sensor	SRH ↔ Body Ground	Resistance	About 5.0 Ω	Actuator

If the circuit is not as specified, check and repair or replace the trouble part shown in the table above.

- (b) Connect the connectors, and install the ECU in place.