

TROUBLESHOOTING

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

See Page	Parts Name		Trouble
CL-7	Clutch pedal (Freeplay out of adjustment)		1
CL-6	Clutch line (Air in line)		2
CL-10	Master cylinder cup (Damaged)		3
CL-13	Release cylinder cup (Damaged)		4
-	Engine mounting (Loosen)		1
CL-15	Release bearing (Worn, dirty or damaged)		1
CL-15	Input shaft bearing (Worn or damaged)		2
CL-15	Clutch disc (Out of true)		
CL-15	Clutch disc (Runout is excessive)		2
CL-15	Clutch disc (Lining broken)		
CL-15	Clutch disc (Dirty or burred)		
CL-15	Clutch disc (Oily)		2
CL-15	Clutch disc (Worn out)		2
CL-15	Clutch disc torsion rubber (Damaged)		2
CL-15	Clutch disc (Harden)		2
CL-18	Clutch disc (Lack of spline grease)		6
CL-15	Diaphragm spring (Damaged)		3
CL-18	Diaphragm spring (Out of tip alignment)		2
CL-15	Pressure plate (Distortion)		4
-	Flywheel (Distortion)		5