


# LIGHT REMINDER BUZZER



## SYSTEM OUTLINE

WITH THE IGNITION SW IN **ACC** POSITION, CURRENT FLOWS TO **TERMINAL 2**. WHEN THE IGNITION SW IS TURNED TO **ON** POSITION, CURRENT FLOWS TO **TERMINAL 1**. WHEN THE LIGHT CONTROL SW IS TURNED TO **TAIL** OR **HEAD** POSITION, CURRENT IS APPLIED TO **TERMINAL 3**.

### LIGHT REMINDER SYSTEM

WHEN THE LIGHT CONTROL SW IS IN **TAIL** OR **HEAD** POSITION, THE IGNITION SW IS TURNED TO OFF FROM ON POSITION, AND THE DRIVER'S DOOR IS OPENED (DOOR COURTESY SW ON), THE CURRENT FLOW TO **TERMINAL 1** AND **2** OF THE LIGHT REMINDER RELAY STOPS. AS A RESULT, THE RELAY IS ACTIVATED AND CURRENT FLOWS FROM **TERMINAL 3** OF THE RELAY → **TERMINAL 4** → **TERMINAL 1** OF DOOR COURTESY SW → TO **GROUND**, SOUNDING THE LIGHT REMINDER BUZZER.

## SERVICE HINTS

### L 1 LIGHT REMINDER RELAY

- 1-GROUND: APPROX. 12 VOLTS WITH IGNITION SW AT **ON** POSITION
- 2-GROUND: APPROX. 12 VOLTS WITH IGNITION SW AT **ACC** OR **ON** POSITION
- 3-GROUND: APPROX. 12 VOLTS WITH LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION
- 4-GROUND: CONTINUOUS WITH FRONT LH DOOR OPEN

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
<b>D12</b>	<a href="#">28</a>	<b>I16</b>	<a href="#">28</a>	<b>L 1</b>	<a href="#">28</a>


## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
<b>1C</b>	<a href="#">20</a>	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

D 12



I16



L 1 ORANGE

