



INSTALLATION

1. INSTALL UPPER BALL JOINT

- (a) Using SST, socket wrench and a press, install a new ball joint.

SST 09309-37010

- (b) Using a snap ring expander, install a new snap ring.
(c) Install a new boot and fix it with a new wire.

HINT:

Use the grease supplied in the kit.

2. INSTALL STEERING KNUCKLE WITH AXLE HUB (See page [SA-14](#))