














PREPARATION

SST (SPECIAL SERVICE TOOLS)

	09032-00100 Oil Pan Seal Cutter	
	09201-10000 Valve Guide Bushing Remover & Replacer Set	Speedometer driven gear oil seal
	(09201-01080) Valve Guide Bushing Remover & Replacer 8	
	09308-10010 Oil Seal Puller	
	09325-40010 Transmission Oil Plug	
	09350-30020 TOYOTA Automatic Transmission Tool Set	
	(09351-32010) One-way Clutch Test Tool	
	(09351-32020) Stator Stopper	
	09843-18020 Diagnosis Check Wire	
	09921-00010 Spring Tension Tool	Speedometer driven gear oil seal
	09992-00094 Automatic Transmission Oil Pressure Gauge Set	

RECOMMENDED TOOLS

	09031-00030 Pin Punch.	
	09905-00012 Snap Ring No.1 Expander.	

EQUIPMENT

Ohmmeter	
Voltmeter	
Torque wrench	
Dial indicator with magnetic base	Check drive plate runout.
Vernier calipers	Check torque converter clutch installation.
Straight edge	Check torque converter clutch installation.

LUBRICANT

Item	Capacity	Classification
A340E Dry fill	7.2 liters (7.6 US qts, 6.3 Imp. qts)	ATF DEXRON® II
Drain and refill	1.6 liters (1.7 US qts, 1.4 Imp. qts)	
A340F Dry fill	7.6 liters (8.0 US qts, 6.7 Imp. qts)	
Drain and refill	2.0 liters (2.1 US qts, 1.8 Imp. qts)	

SSM (SPECIAL SERVICE MATERIALS)

08826-00090 Seal Packing 1281, THREE BOND 1281 or equivalent (FIPG)	Oil pan
08833-00080 Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Extension housing