










PREPARATION

SSM (SPECIAL SERVICE TOOLS)

	09032-00100 Oil Pan Seal Cutter	
	09201-10000 Valve Guide Bushing Remover & Replacer Set	Speedometer driven gear oil seal
	(09201-01080) Valve Guide Bushing Remover & Replacer Set	
	09350-30020 TOYOTA Automatic Transmission Tool Set	
	(09351-32010) One-way Clutch Test Tool	
	(09351-32020) Stator Stopper	
	09843-18020 Diagnosis Check Wire	
	09921-00010 Spring Tension Tool	Speedometer driven gear oil seal
	09992-00094 Automatic Transmission Oil Pressure Gauge Set	

EQUIPMENT

Ohmmeter	
Voltmeter	
Torque wrench	
Dial indicator with magnetic base	Check drive plate runout.
Vernier calipers	Check torque converter clutch installation.
Straight edge	Check torque converter clutch installation.

LUBRICANT

Item	Capacity	Classification
Automatic transmission fluid	10.3 liters (10.9 US qts, 9.1 Imp. qts)	ATF DEXRON® II
Dry fill Transmission	1.1 liters (1.2 US qts, 1.0 Imp. qts)	
Transfer	4.5 liters (4.8 US qts, 4.0 Imp. qts)	
Drain and refill Transmission	0.8 liters (0.8 US qts, 0.7 Imp. qts)	
Transfer		
Drain and refill		

SSM (SPECIAL SERVICE MATERIALS)

08826-00090	Seal Packing 1281, THREE BOND 1281 or equivalent (FIG)	
08833-00070	Adhesive 1324, THREE BOND 1324 or equivalent	