






## PREPARATION

### SST (SPECIAL SERVICE TOOLS)

	<b>09032-00100</b> Oil Pan Seal Cutter	
	<b>09228-07500</b> Oil Filter Wrench	
	<b>09309-37010</b> Transmission Bearing Rsplacer	Camshaft front oil seat
	<b>09816-30010</b> Oil Pressure Switch Socket	

### RECOMMENDED TOOLS

	<b>09200-00010</b> Engine Adjust Kit.	
---	---------------------------------------	--

### EQUIPMENT

Oil pressure gauge	
Precision straight edge	Oil pump
Torque wrench	

### LUBRICANT

Item	Capacity	Classification
Engine oil		API grade SH, Energy-Conserving II or ILSAC multigrade and recommended viscosity oil.
Dry fill	<b>5.4 liters (5.7 US qts, 4.8 Imp. qts)</b>	
Drain and refill	<b>4.2 liters (4.4 US qts, 3.7 Imp. qts)</b>	
w/o Oil filter change w/ Oil filter change	<b>4.5 liters (4.8 US qts, 4.0 Imp. qts)</b>	

**SSM (SPECIAL SERVICE MATERIALS)**

<b>08826-00080</b>	Seal Packing Black or equivalent (FIPG)	Oil pump, Oil pan baffle plate, Oil pan
<b>08833-00080</b>	Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	Oil pressure sender gauge