














# PREPARATION

## SST (SPECIAL SERVICE TOOLS)

	<b>09628-62011</b> Ball Joint Puller	
	<b>09710-26010</b> Front Suspension Bushing Tool Set	Upper arm bushing replacement
	<b>(09710-05020)</b> Handle	
	<b>(09710-05030)</b> Remover	
	<b>(09710-05040)</b> Gate	
	<b>(09710-05050)</b> Remover	
	<b>(09710-05060)</b> Replacer	
	<b>(09710-05080)</b> Rear Base	
	<b>09726-27011</b> Front Suspension Arm Bushing Remover & Replacer	Lower arm bushing replacement
	<b>(09726-02040)</b> Replacer	
	<b>(09726-02050)</b> Remover & Replacer	
	<b>(09726-02060)</b> No.2 Base	

RECOMMENDED TOOLS

	09025-00010 Torque Wrench (30 kgf-cm) .	
---	---	--

EQUIPMENT

Torque wrench	
---------------	--