PREPARATION SST (SPECIAL SERVICE TOOLS)

		0:0 15 "	
	09308-10010		
	09330-00021	Companion Flange Holding Tool	
	09504-00011	Differential Side Bearing Adjusting Nut Wrench	
	09506-30012	Differential Drive Pinion Rear Bearing Cone Replacer	
0000	09550-10012	Replacer Set 'B'	
6	(09252-10010)	No. 1 Replacer Handle	
	(09557-10010)	Differential Drive Pinion Front Bearing Replacer	
@	(09558-10010)	Rear Axle Shaft Oil Seal Replacer	
O j j jui nim	09554-22010	Differential Oil Seal Replacer	
	09556-30010	Drive Pinion Front Bearing Remover	
	09608-35014	Axle Hub & Drive Pinion Bearing Tool Set	
	(09608-06020)	Handle	
	(09608-06110)	Front Hub Inner & Drive Pinion Front Bearing Cup Replacer	

	(09608-06120) Front Hub Replacer	Outer Bearing Cup	
	(09608-06180) Drive Pin Replacer		
	09710-14012 Rear Sus	pension Bushing Toot Set	
9	(09710-00010) Replacer		
	09950 – 00020 Bearing F	Remover	
308 - T	09950 – 30010 Puller A S	Set	
	09950–40010 Puller B S	Set	

RECOMMENDED TOOLS

09025-00010	Torque Wrench (30 kgf-cm).	·
09031-00030	Pin Punch .	

EQUIPMENT

Dial indicator or dial indicator with magnetic base	
Micrometer	
Torque wrench	

LUBRICANT

4 x 4 Type 2.2 liters (2.3 US qts, 1.9 Imp. qts) 4 x 2 Type	API GL-5 Hypoid gear oil [Above - 18° C (0° F)I SAE 90W [Below - 18° C (0°F)] SAE 80W or SOW - 90
	1