



EGR GAS TEMPERATURE SENSOR

EG123-02



FI2673

Z09662



EGR GAS TEMP. SENSOR INSPECTION

MEASURE RESISTANCE OF EGR GAS TEMP. SENSOR

Using an ohmmeter, measure the resistance between both terminals.

Resistance:

At 50°C (122°F): 69 – 89 k Ω

At 100°C (212°F): 11 – 15 k Ω

At 50°C (302°F): 2 – 4 k Ω

If the resistance is not as specified, replace the sensor.